

















 <p>Patch Cord Pkg. of 4 3587-20</p>	 <p>Gray Norr. Spade Male Connector 3587-2A</p>	 <p>Gray Norr. Female Spade Connector 3587-3</p>	 <p>Purple Wide Spade Male Connector 3587-4A</p>	 <p>Purple Wide Spade Female Connector 3587-5</p>
 <p>Brown Micro Pack Male Connector 3587-6</p>	 <p>Brown Micro Pack Female Connector 3587-7</p>	 <p>Orange Weather Pack Male Connector 3587-8</p>	 <p>Orange Weather Pack Female Connector 3587-9</p>	 <p>Dark Blue Male Terminal Probe Connector 3587-40</p>
 <p>Dark Blue Female Terminal Probe Connector 3587-41</p>	 <p>Red Male Terminal Probe Connector 3587-42</p>	 <p>Red Female Terminal Probe Connector 3587-43</p>	 <p>Yellow Male Terminal Probe Connector 3587-44</p>	 <p>Yellow Female Terminal Probe Connector 3587-45</p>
 <p>Light Blue Male Probe Micro 64 3587-64</p>	 <p>Light Blue Female Probe Micro 64 3587-65</p>	 <p>Yellow Male Flexprobe 3587-66</p>	 <p>Yellow Female Flexprobe 3587-67</p>	

TO PREVENT TERMINAL DAMAGE WHILE USING THE PROBE TIPS, PLEASE FOLLOW THESE INSTRUCTIONS:

1. The probe tip should be inserted straight into the cavity and kept stable during testing.
2. Do not wiggle or move the probe tip once it has been inserted into the terminal.
3. The number of probe insertions should be kept to one.