


## WIRING DIAGRAM



### MODEL BCH4050 REPAIR PARTS LIST

Switch w/knob .....	611187	DC Circuit Breaker (1) .....	610069
Axle w/nuts .....	610287	Ammeter .....	610695
Wheels w/nuts .....	605672	AC Cord .....	605206
Transformer .....	611199	DC Cable Set .....	611204
Rectifier .....	611200	Handle .....	610753
Fan Blade .....	611201	Cabinet, Front-Base-Back .....	611244
Fan Motor .....	611202	Cabinet, Top-Sides .....	611243
Leg .....	610825	Timer, Electric .....	611245

### MAINTENANCE INSTRUCTIONS

Worn clamps should be replaced. Worn parts can lead to poor connections and present a safety hazard. See parts list for part number of DC Cable Set. Any Maintenance or repair of this unit that involves disassembly of the cabinet should be done only by a qualified serviceman. Incorrect reassembly may result in a risk of electric shock when the unit is subsequently used.

ASSOCIATED EQUIPMENT  
 5043 Farlin Ave.  
 St. Louis MO 63115  
 ATTN. SERVICE REPAIR

For local service in your area go to [www.associatedequip.com](http://www.associatedequip.com) and click on Repair Centers.