



PARTS LIST

KEY NO.	DESCRIPTION	QTY	PART NO.
1	Glide	4	CR1011-3
2	Leg	4	CR1011-7
3	Foot Ring	1	CR1011-8
4	1/4-20 x 1 1/4" Phillips Serrated Washer Pan Head Screw	4	CR1011-9
5	Cylinder Support Tube	4	CR1011-10
6	5/16"-18 Fiber Hex Nut	4	CR1011-11
7	5/16" Lock Washer	4	CR1011-12
8	5/16" Flat Washer	4	CR1011-13
9	Hub Bracket	1	CR1011-14
10	5/16-18 x 2" Carriage Bolt	4	CR1011-15
11	Lift Assembly	1	CR1011-4
12	Hub Cover	1	CR1011-16
13	1/4-20 x 1" Phillips Serrated Washer Pan Head Screw	4	CR1011-17
14	1/4" Flat Washer	4	CR1011-18
15	Control Assembly	1	CR1011-19
16	Left Back Bar Support Bracket	1	CR1011-20
17	Seat	1	CR1011-1
18	Knob	2	CR1011-21
19	Right Back Bar Support Bracket	1	CR1011-22
20	Back Bar	2	CR1011-23
21	1/4-20 x 2" Phillips Serrated Washer Pan Head Screw	4	CR1011-24
22	Back	1	CR1011-25