

WHEEL HUB CLEANING TOOL (STLWH1) Instruction Sheet



Securely attach the wheel hub cleaning tool to an impact wrench.

Only operate the impact wrench in the FORWARD (clockwise) settings so that the pad remains secure during operation.

Operating the tool in REVERSE will cause the abrasive pad to detach.



Place the wheel hub cleaning tool over a wheel mounting stud and start the impact wrench to clean away rust and corrosion from the hub. Repeat this process for additional studs requiring cleaning/resurfacing.



Replace worn pad promptly with a genuie Mac Tools cleaning pad,available in a 6-piece set (STLWH1PD).

